


GROUNDING NOMOGRAPH



Represents example of a 20 , 20-foot ground rod.

1. Select required resistance on R scale.
2. Select apparent resistivity on P scale.
3. Lay straightedge on R and P scale, and allow to intersect with K scale.
4. Mark K scale point.
5. Lay straightedge on K scale point and DIA scale, and allow to intersect with D scale.
6. Point on D scale will be the rod depth required for resistance on R scale.